SYMBOL	PLATE	DESCRIPTION
137E	39	Guard, on Auxiliary Bracket
138E	39	Operating Bar Lever
139E	39	Operating Bar Lever Fulcrum Pin
140E	35	Centring Pin Lever Gag Block
141E	39	Spring Box
142E	39	Spring Box Lever
143E	39	Spring Box Lever Fulcrum Pin
144E	39	Spring Box Lever Link
145E	39	Spring Box Lever Link Pin
146E	56	Clutch
148E	40	Shear Cam
168E	12	Camshaft Stand Packing Piece
169E	29	Starting Bar
170E	29	Starting Bar Lock Bracket
171E	29	Starting Bar Lock Bracket Stud
172E	29	Starting Bar Stud
173E	56	Clutch Shifter Arm Rod Lever
174E	56	Cone Pulley and Lever
175E	56	Pulley Lever Bracket
197E	29	Nameplate
198E	36	Patent Plate
199E	13	Oil Splash Guard, large
200E	13	Oil Splash Guard, small
209E	50	Air Pipe
210E	50	Air Pipe
211E	50	Air Pipe
212E	50	Air Pipe
213E	50	Air Pipe
214E	50	Air Pipe
215E	50	Air Pipe Connection Block
216E	50	Valve Box, Control
217E	36	Gear Cover, bottom
218E	50	Air Pipe
222E	43	Valve Box, Unit Adding
245E	57	Valve Box
293E	58	Air Pipe
294E	59	Bracket
295E	59	Switch Box
296E	59	Valve Box "Mathematical"
297E	59	Valve Operating Arm
301E	52	Speed Indicator
302E	60	Valve Box, "Unit Shift"
303E	60	Valve Box, Constant Air, "Unit Shift"
304E	60	Valve Box, "Unit Shift"
305E	60	Air Pipe, Valve Box, "Unit Shift"
1F	17	Column Pusher
2F	18	Column Pusher Adjusting Cam
3F	18	Column Pusher Adjusting Cam Stand
4F	17	Column Pusher Fulcrum Screw
5F	19	Column Pusher Lever
6F	19	Column Pusher Lever Stud
7F	20	Column Pusher Spring
8F	20	Column Pusher Spring Box
9F	21	Column Support, No. 4
10F	21	Column Support, No. 5
11F	21	Column Support, No. 6
13F	19	Galley Bar
14F	19	Galley Cam
15F	19	Galley Camshaft
16F	18	Galley Cam Stand
17F	19	Galley Pan Shelf
18F	18	Galley Pan Support
19F	19	Line Hook
20F	20	Line Hook Carriage
21F	20	Line Hook Operating Bar
22F	20	Line Hook Operating Bar Stop
23F	20	Line Hook Operating Slide
24F	20	Line Hook Operating Slide Shoe
25F	19	Line Hook Operating Slide Lever
26F	19	Line Hook Operating Slide Lever Stud
27F	20	Line Hook Operating Slide Spring Box
28F	19	Line Hook Stud
29F	21	Line Support, thin
30F	21	Line Support, thick
31F	20	Main Galley Stand
32F	18	Operating Lever
33F	19	Operating Lever Latch
34F	18	Operating Lever Latch Spring
35F	18	Operating Lever Latch Spring Post, in Main Galley Stand
36F	18	Operating Lever Latch Stand
37F	18	Operating Lever Spring Box
38F	20	Operating Lever Stud
39F	18	Rule
40F	18	Rule Lever
41F	18	Rule Lever Stud
42F	18	Tool Tray
43F	18	Tool Tray Support Bar
44F	19	Stop Slide
45F	20	Trip Lever
46F	19	Trip Lever Fulcrum Rod
47F	20	Trip Lever Spring
48F	20	Trip Lever Spring Post
49F	19	Type Channel Plate
50F	17	Type Channel Block, adjustable
51F	17	Type Channel Block, fixed
52F	21	Column Support, No. 3
53F	20	Line Hook Operating Slide Latch
54F	19	Line Support Pusher
55F	20	Line Support Pusher Catch Plate
70F	29	Type Channel Block Stand
71F	44	Operating Lever

SYMBOL	PLATE	DESCRIPTION
72F	21	Column Support, No. 1
73F	21	Column Support, No. 2
76F	40	Box, for short Leads
77F	41	Channel Bar
78F	41	Galley
79F	39	Guide Plate
80F	41	Guide Roller
81F	41	Main Bracket
82F	40	Main Bracket Buffer
83F	42	Shear Blade
84F	41	Shear Blade Guide
85F	41	Shear Blade Shoe
86F	41	Shear Blade Shoe Tube Clamp
87F	41	Shear Blade Shoe Tube Guide
88F	41	Shear Gauge
89F	41	Shear Gauge Spring
90F	40	Stacker Plate
91F	40	Stacker Rock Shaft
92F	41	Stack Support Block
93F	41	Supporting Beam
94F	41	Supporting Beam Bracket, right
95F	41	Supporting Beam Bracket, left
96F	41	Transfer Bar, rear
97F	40	Transfer Bar, front
100F	40	Transfer Bar Hanger Rod
101F	42	Transfer Bar Operating Lever
102F	42	Transfer Bar Operating Lever Adjusting Screw
103F	42	Transfer Bar Hanger Spring, long
104F	41	Transfer Bar Hanger Spring, short
105F	40	Patent Plate
106F	42	Main Bracket Screw
107F	40	Main Bracket Shield
108F	42	Shear Bell Crank
109F	42	Shear Bell Crank Adjusting Screw
110F	40	Shear Cam Lever
111F	40	Shear Cam Lever Fulcrum Pin
112F	29	Shear Cam Lever Fulcrum Pin
113F	40	Shear Cam Lever Fulcrum Pin Bracket
114F	40	Shear Cam Lever Spring
115F	42	Shear Operating Pin
116F	41	Shear Trip Lever
117F	40	Shear Trip Lever Spring
118F	42	Shear Trip Lever Spring Bar
119F	42	Shear Yoke
120F	42	Shear Yoke Spring
121F	41	Stacker Rock Shaft Connecting Rod
122F	40	Thrust Bar
123F	40	Thrust Bar Bell Crank
124F	40	Thrust Bar Bell Crank Fulcrum Pin
125F	42	Thrust Bar Bell Crank Operating Bar
126F	42	Thrust Bar Bell Crank Spring, short
127F	40	Thrust Bar Bell Crank Spring, long
128F	42	Thrust Bar Latch
129F	42	Thrust Bar Operating Rod
132F	46	Column Pusher
133F	46	Column Pusher Guide Bar Spring
134F	46	Column Pusher Guide Bar Lever
135F	46	Column Pusher Guide Bar Lever Bracket
136F	46	Lifting Frame
137F	46	Lifting Frame Adjusting Lever
138F	46	Lifting Frame Adjusting Lever Spring
139F	46	Lifting Frame Adjusting Lever Bell Crank
140F	46	Lifting Frame Adjusting Lever Bell Crank Slide
141F	46	Lifting Frame Adjusting Lever Bell Crank Spring
142F	46	Lifting Frame Lifting Rod
143F	45	Galley Pan Shelf, left
146F	46	Nameplate
148F	45	Stop Slide Trip Bar
149F	45	Type Channel Block Bracket
150F	45	Type Channel Block Bracket Screw
175F	41	Shear Blade Shoe Tube Friction Plate
176F	40	Transfer Bar Guard
200F	47	Lead Depressor
201F	47	Lead Galley
202F	48	Lead Galley Operating Lever
203F	47	Lead Galley Support Block
204F	47	Lead Pusher
205F	47	Rule Guide
206F	48	Valve Box
207F	48	Valve Box Air Piping
208F	48	Galley Cut-out
211F	21	Line Support Pusher Spring Box
212F	21	Line Support Pusher Spring Box Chain
213F	48	Galley Cam Guard
217F	49	Line Support Pusher Catch
218F	49	Trip, Repeater
219F	49	Trip Gauge Bar, Repeater
220F	50	Valve, Repeater Release
1G	22	Air Tower Housing
2G	23	Air Bar, including Valve Body
3G	22	Air Bar Clamping Lever
4G	23	Air Bar Clamping Lever Connecting Rod
5G	23	Air Bar Shaft
6G	23	Air Pipe, to Air Bar
7G	22	Air Pipe Cover, right
8G	23	Air Pipe Cover, left

SYMBOL	PLATE	DESCRIPTION
9G	22	Basket
10G	23	Nameplate
11G	22	Paper Tension Roller
12G	22	Paper Feed Locking Lever
13G	22	Paper Feed and Locking Pawl
14G	22	Paper Feed Pawl Ring
15G	22	Paper Feed Pawl Stud, lower
16G	22	Paper Feed Pawl Stud, upper
17G	23	Paper Feed Spring Box
18G	23	Paper Tension Bar
19G	22	Air Tower Lever
20G	22	Pin Wheel
21G	23	Winding Spool
22G	22	Winding Spool Driving Shaft
23G	22	Winding Spool Driving Ratchet
24G	22	Winding Spool Operating Spring
25G	23	Winding Spool Spring Box Plunger
26G	44	Copy Repeater
27G	23	Paper Reader
28G	50	Control Box, "Repeater", Paper Feed
29G	49	Control Plate, "Quadding"
30G	51	Paper Ribbon Rewinder
1H	27	Air Pipe
2H	27	Air Cock
9H	27	Gas Pipe
12H	24	Melting Pot
13H	24	Melting Pot Chimney
14H	26	Nozzle
16H	27	Pipe Bracket
17H	26	Piston
18H	24	Piston Lever
19H	25	Piston Operating Rod
20H	25	Piston Spring
21H	25	Pump Bell Crank
22H	14	Pump Bell Crank Connecting Rod
23H	26	Pump Body and Piston
24H	25	Pump Body Lever
25H	24	Pump Body Lifting Lever, Piston End
26H	25	Pump Body Lifting Lever, Nozzle End
27H	24	Pump Body Lifting Spring
28H	24	Pump Body Operating Rod
29H	24	Pump Body Operating Rod Lever
31H	24	Pump Body Spring
32H	24	Pump Lever Connecting Link
33H	14	Pump Rocker Arm
34H	14	Pump Operating Lever
35H	10	Pump Trip (Hand)
37H	25	Swing Frame
38H	25	Swing Frame Post
39H	25	Swing Frame Rack
40H	25	Swing Frame Wormshaft Crank
42H	27	Water Escape Valve
43H	27	Water Pipe, Drain
44H	27	Water Pipe, Drain
45H	27	Water Supply Pipe
46H	27	Water Pipe, Drain
47H	27	Water Pipe Connection, side, on Main Stand
48H	27	Water Supply Valve
49H	28	Gas Hose, Armoured
52H	27	Water Supply Valve and Piping
53H	28	Melting Pot, Heater and Temperature Regulator, Electric
55H	28	Gas Burner
57H	35	Latch
58H	35	Latch Abutment
59H	35	Latch Abutment Spring
60H	35	Latch Pin
61H	35	Latch Spring
62H	35	Latch Stand
63H	35	Pump Body Spring Rod Stop Plate
66H	55	Ingot Feeder
67H	55	Support
70H	28	Temperature Regulator, Gas
73H	56	Blower Casing
75H	56	Blower Casing Cover, front
76H	56	Blower Casing Cover, rear
77H	56	Blower Pulley
78H	56	Blower Rotor
79H	56	Blower Support Bracket
161H	51	Pump Stroke Counter
162H	52	"Pluslite"
163H	52	Lamp
1CK101	32	Air Filter, felt
1CK108	30	Air Flange
1CK115	32	Air Valve
1CK119	31	Ball Bearing, for Crankshaft
1CK125	31	Connecting Rod
1CK131	31	Crankshaft
1CK139	30	Cylinder Block
1CK144	30	Cylinder Head
1CK148	31	Flywheel
1CK149	30	Nameplate
1CK151	30	Oil Chamber and Air Filter Case
1CK158	32	Oil Feed Adjusting Valve
1CK162	30	Oil Filler
1CK168	32	Oil Filter
1CK170	30	Oil Pump Housing
1CK176	32	Oil Pump Piston
1CK181	32	Oil Pump, Valve
1CK188	32	Oil Tray, in Cylinder Block
1CK190	30	Oiling Instruction Plate