

Melting Pot Chimney	13H	Pin Jaw Tongs Stud	63E	Space Transfer Wedge Operating Rod Guide	54D
Micrometer	8CT	Pin Wheel	20G	Special Timetable Equipment Attachment	84CU
Micrometer Wedge	20D	Pipe Bracket	16H	Speed Bracket	122E
Motor Base	23CT, 25CT	Piston	17H, 1CK192	Speed Bracket Cone Shaft	123E, 124E, 125E
Motor Belt Guard Attachment	67CU	Piston Lever	18H	Speed Bracket Quadrant	126E
Motor Drive Attachment	29CU	Piston Operating Rod	19H	Speed Bracket Quadrant Shaft	129E
Mould Assembling Outfit	31CU	Piston Operating Sliding Frame Draw Rod	44B	Speed Bracket Screw	130E
Mould Blade Abutment Slide	27CT	Piston Spring	20H	Speed Bracket Sliding Shaft	131E
Mould Blade Abutment Slide Spring	14C	"Pluslite"	162H	Speed Index Plate	132E
Mould Blade Abutment Slide Abutment	15C	Point Measure Gauge	8CT	Speed Indicator Attachment	98CU
Screw Packing Piece	32C	Precision Tools	35CT	Spring Box	141E
Mould Blade Bell Crank	41E	Pulley, driving	64E	Spring Box Lever	142F
Mould Blade Bell Crank Stud	42E	Pulley, loose	65E	Spring Box Lever Fulcrum Pin	143E
Mould Blade Cam	43E	Pulley Lever Bracket	175E	Spring Box Lever Link	144E
Mould Blade Cam Lever	44E	Pump Bell Crank	21H	Spring Box Lever Link Pin	145E
Mould Blade Cam Lever Compound	96E	Pump Bell Crank Connecting Rod	22H	Stack Support Block	92F
Lever Abutment		Pump Body	23H	Stacker Plate	90F
Mould Blade Connecting Rod	45E	Pump Body Lever	24H	Stacker Rock Shaft	91F
Mould Blade Connecting Rod Ball Socket	46E, 47E	Pump Body Lifting Lever	25H, 26H	Stacker Rock Shaft Connecting Rod	121F
Mould Blade Micrometer Wedge	51B	Pump Body Lifting Spring	27H	Starting Bar	169E
Mould Blade Operating Bar	53B	Pump Body Operating Rod	28H	Starting Bar Lock Bracket	170E
Mould Blade Operating Rod	16C	Pump Body Operating Rod Lever	29H	Starting Bar Lock Bracket Stud	171E
Mould Clamp	48E, 49E, 89E	Pump Body Spring	31H	Starting Bar Stud	172E
Mould Coupling Hook	56B	Pump Body Spring Rod Stop Plate	63H	Stop Slide	44F
Mould Oiler	11CT, 44CT	Pump Cam	66E	Stop Slide Trip Bar	148F
Mould Screw	50E, 51E	Pump Cam Lever	67E	Support	67H
		Pump Cam Lever Connecting Rod	68E	Supporting Beam	93F
		Pump Cleaning Equipment	48CT	Supporting Beam Bracket	94F, 95F
		Pump Lever Connecting Link	32H	Switch Box	295E
N Nameplate	197E, 105F, 146F, 10G, 1CK149	Pump Operating Lever	34H	Swing Frame	37H
		Pump Piston Extractor	31CT	Swing Frame Post	38H
		Pump Rocker Arm	33H	Swing Frame Rack	39H
		Pump Stroke Counter	161H	Swing Frame Wormshaft Crank	40H
		Pump Stroke Counter Attachment	80CU		
Normal Wedge	21D	Pump Trip	35H	T Temperature Regulator	70H
Normal Wedge Abutment	17C	Pump Trip Operating Lever	48D	Thermometer	12CT
Normal Wedge Locking Pin	14B	Pump Trip Tube	49D	Thrust Bar	122F
Normal Wedge Locking Pin Stand	15B	Pump Trip Spring	50D	Thrust Bar Bell Crank	123F
Normal Wedge Position Plate	67D	Pump Trip Tube Spring Post	51D	Thrust Bar Bell Crank Fulcrum Pin	124F
Nozzle	14H			Thrust Bar Bell Crank Operating Bar	125F
Nozzle Drill	4CT	Q Quad and Space Mould Attachment	90CU	Thrust Bar Bell Crank Spring	126F, 127F
Nozzle Gauge	8CT	Quadding and Centring Attachment	61CU	Thrust Bar Latch	128F
Nozzle Squaring Post	8CT			Thrust Bar Operating Rod	129F
Nozzle Tap	4CT	R Reverse Delivery Attachment	23CU	Tool Tray	42F
		Rock Lever	25D	Tool Tray Support Bar	43F
O Oil Can	14CT	Rock Lever Lifting Rod	25D	Transfer Bar	96F, 97F
Oil Chamber and Air Filter Case	1CK151	Roller Bearing	1CK197	Transfer Bar Guard	176F
Oil Feed Adjusting Valve	1CK158	Rule	39F	Transfer Bar Hanger Rod	100F
Oil Filler	1CK162	Rule Dotting Attachment	22CU	Transfer Bar Hanger Spring	103F, 104F
Oil Filter	1CK168	Rule Guide	205F	Transfer Bar Operating Lever	101F
Oil Guard	113E	Rule Lever	40F	Transfer Bar Operating Lever Adjusting	102F
Oil Instruction Plate	1CK190	Rule Lever Stud	41F	Screw	59D
Oil Pan	114E	S Screwdrivers	5CT	Transfer Tongs	59D
Oil Pan Shelf	115E	Selecting Lever	16E	Transfer Wedge Cam	69E
Oil Pan Shelf Bracket Bolt	116E	Selecting Lever Cam Lever	16E	Transfer Wedge Cam Lever	70E
Oil Pump Eccentric	1CK207	Selecting Lever Switch Box	43A, 55A, 78A	Transfer Wedge Operating Rod Guide	68D
Oil Pump Housing	1CK170	Shear Bell Crank	108F	Transfer Wedge Shifter	55D
Oil Pump Piston	1CK176	Shear Bell Crank Adjusting Screw	109F	Transfer Wedge Shifter Lever	56D
Oil Pump Valve	1CK181	Shear Blade	83F	Transfer Wedge Shifter Lever Arm	57D
Oil Splash Guard	199E, 200E	Shear Blade Guide	84F	Transfer Wedge Shifter Lever Arm Spring	58D
Oil Tray	1CK188	Shear Blade Screw Tube Friction Plate	175F	Transfer Wedge Spring Box	60D
Operating Bar Lever	138E	Shear Blade Shoe	85F	Transfer Wedge Spring Box Stand	61D
Operating Bar Lever Fulcrum Pin	139E	Shear Blade Shoe Tube Clamp	86F	Trip Gauge Bar	219F
Operating Lever	32F, 71F	Shear Blade Shoe Tube Guide	87F	Trip Lever	45F
Operating Lever Latch	33F	Shear Cam	148E	Trip Lever Fulcrum Stud	46F
Operating Lever Latch Spring	34F	Shear Cam Lever	110F	Trip Lever Spring	47F
Operating Lever Latch Spring Post	35F	Shear Cam Lever Fulcrum Pin	111F, 112F	Trip Lever Spring Post	48F
Operating Lever Latch Stand	36F	Shear Cam Lever Fulcrum Pin Bracket	113F	Trip Repeater	218F
Operating Lever Spring Box	37F	Shear Cam Lever Spring	114F	Tumbler	133E
Operating Lever Stud	38F	Shear Gauge	88F	Tweezers	10CT
Operating Stand	25D	Shear Gauge Spring	89F	Two Colour Attachment	81CU
Orderly Box	15CT	Shear Operating Pin	115F	Type Alignment Gauge	8CT
Overhung Type Attachment	28CU	Shear Trip Lever	116F	Type Alignment Slip Gauge	36CT
		Shear Trip Lever Spring	117F	Type Carrier	20B
P Paper Feed Locking Lever	12G	Shear Trip Lever Spring Bar	118F	Type Carrier Cam	71E
Paper Feed and Locking Pawl	13G	Shear Yoke	119F	Type Carrier Cam Lever	72E
Paper Feed Pawl Ring	14G	Shear Yoke Spring	120F	Type Carrier Connecting Rod	21B
Paper Feed Pawl Stud	15G, 16G	Short Lead and Rule Attachment	53CU	Type Carrier Extension	22B
Paper Feed Spring Box	17G	Skimming Spoon	3CT	Type Carrier Shoe	23B, 24B
Paper Reader	27G	Slide	25D	Type Carrier Spring Abutment Stand	25B
Paper Ribbon Rewinder	30G	Slide Distance Piece	25D	Type Channel Block	50F, 51F
Paper Ribbon Rewinder Attachment	82CU	Slide Distance Piece Tool	88CT	Type Channel Block Bracket	149F
Paper Tension Bar	18G	Slide Operating Lever	25D	Type Channel Block Bracket Screw	150F
Paper Tension Roller	11G	Sliding Frame	9A	Type Channel Block Stand	70F
Patent Plate	198E, 105F	Sliding Gear	117E	Type Channel Plate	49F
Pin Jaw	16B, 17B, 18C, 19C	Sliding Gear Hollow Shaft	120E	Type Clamp	26B
Pin Jaw Guide Rod	18B, 20C	Sliding Gear Safety Lever	121E	Type Clamp Shoe	27B
Pin Jaw Guide Rod Stand	36B, 22C, 23C	Sliding Gear Shifter	118E	Type Pusher	29B
Pin Jaw Guide Rod Stop	19B, 21C	Sliding Gear Shifter Yoke	119E	Type Pusher Bell Crank	73E
Pin Jaw Tongs	55E, 56E	Sorts Matrix Storage Box	47CT	Type Pusher Bell Crank Fulcrum Stud	74E
Pin Jaw Tongs Spring	57E	Space and Type Transfer Wedge	78CU	Type Pusher Cam	75E
Pin Jaw Tongs Spring Bell Crank	58E	Operating Rods (increased diameter threaded end) Attachment		Type Pusher Cam Lever	76E
Pin Jaw Tongs Spring Bell Crank Stud	59E	"Space" Blade	79A	Type Pusher Connecting Rod	77E
Pin Jaw Tongs Spring Connecting Link	60E, 61E	Space Casting Attachment	32CU	Type Pusher Connecting Rod Ball Socket	78E
Pin Jaw Tongs Spring Lever	62E	Space Casting Bracket	60A	Type Pusher Guide	28B
		Space Transfer Wedge	52D	Type Support Spring	31B
		Space Transfer Wedge Operating Rod	53D	Type Transfer Wedge	62D
				Type Transfer Wedge Operating Rod	63D
				Type Tray Holder	15CT