

5B
*d5B** † Matrix Jaw, left, for Matrix Jaw Tongs
e5B† Matrix Jaw, left, for Matrix Jaw Tongs
*Xf5B** † Matrix Jaw, left, group; consists of *d5B*,
Xd7B
Xg5B† Matrix Jaw, left, group; consists of *e5B*,
Xd5B
 *Composition Casters numbered 26120 to
 26952 inclusive were equipped with these
 parts
 †Can be fitted only at Workshops

6B
*b6B** † Matrix Jaw, right, for Matrix Jaw Tongs,
 front
c6B Matrix Jaw, right, for Matrix Jaw Tongs,
 front
 *Composition Casters numbered 22001 to
 26952 inclusive were equipped with these
 parts
 †Can be fitted only at Workshops

7B
*c7BB** Matrix Jaw Latch
b7B1 Pin
b7B2 Spring
b7B3 Stud Nut
a7B4 Stud
a7B5 Stud Nut Lock Nut
b7B6 Stud Washer
Xd7B Matrix Jaw Latch group; consists of *c7BB*,
b7B2, *b7B3*, *a7B4* and 5, *b7B6*
 **c7BB* consists of *c7B*, *b7B1*

9B
 Matrix Jaw Shoe Packing Block, left, large
a9B5 Clamp, lower
a9B6 Clamp, upper
a9B7 Clamp Screw, $\frac{3}{16}'' \times 1\frac{1}{16}''$

12B
g12B Matrix Jaw Stop Rack, front, wide

13B
g13B Matrix Jaw Stop Rack Locking Bar, front
a13B4 Connecting Bar
b13B5 Spring
Xg13B Matrix Jaw Stop Rack Locking Bar, front,
 group; consists of *g13B*, *a13B4*, *b13B5*

16B
*a16BB** Pin Jaw, left
 16B1 Stud
 16B2 Stud Nut
 16B3 Stud Washer
 16B5 Abutment Collar
a16B5 Abutment Collar, "Unit Shift"
Xb16B Pin Jaw, left, group; consists of *a16BB*,
 16B2 and 3, 16B5
Xc16B Pin Jaw, left, "Unit Shift", group; consists
 of *a16BB*, 16B2 and 3, *a16B5*
 **a16BB* consists of *a16B*, 16B1

17B
*a17BB** Pin Jaw, right
 17B1 Stud
 17B2 Stud Nut
 17B3 Stud Washer
 17B4 Abutment Collar
Xa17B Pin Jaw, right, group; consists of *a17BB*,
 17B2, 3 and 4
 **a17BB* consists of *a17B*, 17B1

18B
c18B Pin Jaw Guide Rod (Not supplied separately,
 order *Xc18B*)
b18B1 Screw
Xc18B Pin Jaw Guide Rod group; consists of
c18B, *b18B1*

19B
 19B Pin Jaw Guide Rod Stop

20B
*d20BB** † Type Carrier (specify type height)
b20B1 Lever Stand
a20B2 Lever Stand Rivet (2)
d20B3 Lever, to Type Support Spring
b20B4 Lever Pin
a20B5 Shield
 20B6 Shield Screw (2), $\frac{3}{32}'' \times \frac{7}{64}''$
a20B9 Lever Pin Split Pin, $\frac{1}{16}'' \times \frac{3}{8}''$
a20B10 Bush
a20B11 Lever, for Type Clamp
b20B11 Lever, for Type Clamp, Short Lead and
 Rule Attachment (see Plate 35)
a20B12 Lever Pin
Xd20B† Type Carrier (specify type height) group;
 consists of *d20BB*, *b20B1*, *a20B2*(2),
d20B3, *b20B4*, *a20B5*, 20B6(2), *a20B9*,
a20B11 and 12, 21B1B, *Xd26B*, *Xc27B*,
Xc31B
 **d20BB* consists of *d20B*, *a20B10*
 †Can be fitted only at Workshops

21B
 21B Type Carrier Connecting Rod
 21B1B* Yoke, Carrier End
 21B2 Yoke Lock Nut
 21B3† Yoke Pin
 21B4 Yoke Taper Pin, $\frac{5}{32}'' \times \frac{3}{4}''$
a21B5 Yoke Eye, Cam Lever End
 21B6 Yoke Lock Nut
 21B7 Yoke Pin
 21B8 Yoke Pin Split Pin, $\frac{3}{32}'' \times \frac{3}{8}''$
 21B9 Spring
 21B10 Spring Abutment
 21B11 Sleeve
Xa21B Type Carrier Connecting Rod group; con-
 sists of 21B, 21B1B, 21B2, *a21B5*, 21B6
 to 11 inclusive
 *21B1B consists of 21B1, 21B3 and 4
 †Can be fitted only at Workshops

22B
a22B Type Carrier Extension
 22B1 Lock Nut
a22B2 Sleeve
 22B4 Spring
Xa22B Type Carrier Extension group; consists of
a22B, 22B1, *a22B2*, 22B4

25B
a25B Type Carrier Spring Abutment Stand
 25B1 Screw, front (2), $\frac{1}{4}'' \times 1''$
 25B2 Screw, top, $\frac{1}{4}'' \times \frac{3}{8}''$
Xa25B Type Carrier Spring Abutment Stand
 group; consists of *a25B*, 25B1(2), 25B2

26B
d26B Type Clamp
 b26B1 Extension
 a26B2 Spring
Xd26B Type Clamp group; consists of *d26B*,
 b26B1, a26B2

27B
c27B Type Clamp Shoe
 a27B1 Screw (3), $\frac{3}{32}'' \times \frac{11}{16}''$, countersunk
Xc27B Type Clamp Shoe group; consists of *c27B*,
 a27B1(3)

29B
e29B Type Pusher
*d29BB** Type Pusher, Raised Galley Attachment
 b29B1† Blade, Raised Galley Attachment
 29B2 Blade Rivet, Head end (2), Raised Galley
 Attachment
 29B3 Blade Rivet, Eye end, long, Raised Galley
 Attachment
 29B4 Blade Rivet, Eye end, short, Raised
 Galley Attachment
 a29B5 Eye, Raised Galley Attachment
 a29B6 Eye Pin
 29B7 Eye Pin Split Pin, $\frac{3}{32}'' \times \frac{1}{2}''$
Xe29B Type Pusher group; consists of *e29B*,
 a29B6, 29B7
 **d29BB* consists of *d29B*, *b29B1*, 29B2(2),
 29B3 and 4, *a29B5*
 †Can be fitted only at Workshops

31B
b31B Type Support Spring
 f31B1B* Bar
 a31B2 Bar Rivet (2)
 c31B4 Bar Yoke
 a31B6 Bar Spring
 a31B7 Bar Extension
Xc31B Type Support Spring group; consists of
 f31B1B, c31B4, a31B6 and 7
 *f31B1B consists of b31B, f31B1, a31B2(2)

44B
 44B1 Piston, Operating Sliding Frame Draw Rod
 44B2 Seating Ring