

‡Composition Casters numbered 22001 to 22182 inclusive were equipped with these parts

35H

Pump Trip (Hand)

b35H1H* Rod
c35H1H† Rod, Unit Adding Attachment (see Plate 43)
35H2 Rod Nut
35H3 Rod Washer
35H4 Rod Plate
a35H5 Rod Plate Rivet (2)
a35H12 Handle
a35H8 Handle Nut
35H9 Handle Spring
b35H10 Rod Stop Nut
a35H11 Rod Stop Washer
a35H12 (refer after a35H5)
Xb35H Pump Trip (Hand) group; consists of b35H1H, 35H2 and 3, a35H8, 35H9, b35H10, a35H11 and 12
*b35H1H consists of b35H1, 35H4, a35H5(2)
†c35H1H consists of c35H1, 35H4, a35H5(2)

78CU

Space and Type Transfer Wedge Operating Rod (increased diameter threaded end) Attachment

Object—To prevent breakage of the Space and Type Transfer Wedge Operating Rods

For Composition Casters numbered 22001 to 22182 inclusive

78CU **Space and Type Transfer Wedge Operating Rod (increased diameter threaded end) Attachment; consists of Xb53D, Xb63D**
Note. When applying this attachment it will be necessary for the customer's existing transfer Tongs X59D to be returned for new Crossheads to be fitted. Loan Tongs can be supplied while customer's Tongs are being converted