

- 76E1 Ball Extension
- 76E2* Bush (2)
- 76E3 Bush Pin (2)
- 76E4 Roller
- 76E4r1 Roller, 1st repair, .016" oversize
- 76E4r2 Roller, 2nd repair, .031" oversize
- 76E4r3 Roller, 3rd repair, .047" oversize
- 76E4r4 Roller, 4th repair, .063" oversize
- 76E5 Roller Pin
- X76E Type Pusher Cam Lever group; consists of
76E, 76E1, 76E2(2), 76E3(2), 76E4 and 5
*Can be fitted only at Workshops

86E

- c86E* **Locking Bar Cam** (marked I.3 in circle)
*Can be fitted only at Workshops

I 13E

- 113E1 **Oil Guard**

I 14E

- a114E1 **Oil Pan**

I 15E

- a115E1E* **Oil Pan Shelf**
- 115E2 Bracket, front
- 115E3 Bracket, rear
- a115E6 Link (4)
- a115E7 Link Fulcrum Pin, upper (4)
- a115E8 Link Fulcrum Pin Washer (4)
- a115E9 Link Fulcrum Stud, lower (4)
- 115E10 Link Fulcrum Stud Nut (4)
- a115E12 Stop Pin (2)
- X115E Oil Pan Shelf group; consists of a115E1E,
115E2 and 3, a115E9(4), 115E10(4)
*a115E1E consists of a115E1, a115E6(4),
a115E7(4), a115E8(4), a115E12(2)

I 16E

- 116E1 **Oil Pan Shelf Bracket Bolt** (8), $\frac{3}{8}'' \times 1\frac{3}{8}''$

I 68E

- 168E1 **Cam Shaft Stand Packing Piece** (2)