

2F					
a2F	Column Pusher Adjusting Cam, point (Not supplied separately, order Xa2F)	a36F			
b2F	Column Pusher Adjusting Cam, didot (Not supplied separately, order Xb2F)	36F1			
a2F1*	Disc (see Plate 19)	Xa36F			
b2F1*	Disc, Reverse Delivery Attachment (see Plate 46)				
2F2	Disc Pin (see Plate 19)				
2F3	Disc Taper Pin	37F			
Xa2F	Column Pusher Adjusting Cam, point, group; consists of a2F, a2F1, 2F2 and 3	a37FF*			
Xb2F	Column Pusher Adjusting Cam, didot, group; consists of b2F, a2F1, 2F2 and 3	b37F			
	*Can be fitted only at Workshops				
3F					
a3FF*	Column Pusher Adjusting Cam Stand	37F1			
a3F1	Spring	37F2			
a3F2	Stud	37F3			
3F3	Stud Nut (2)	a37F3			
Xa3F	Column Pusher Adjusting Cam Stand group; consists of a3F1, 3F3(2)	a37F5†			
	*a3FF consists of a3F, a3F1 and 2.	X37F			
15F		Xa37F			
15F3	Galley Cam Shaft	Xb37F			
a15F4	Worm Wheel Worm Wheel Oil Pan				
16F					
16F	Galley Cam Stand	c39FF*			
16F1	Taper Pin, $\frac{11}{32}'' \times 1\frac{1}{2}''$	e39FF†			
16F2	Screw (4), $\frac{3}{8}'' \times \frac{7}{8}''$	h39FF†			
X16F	Galley Cam Stand group; consists of 16F, 16F1, 16F2(4)	c39F1§			
		d39F1§			
17F		a39F2			
a17F6	Galley Pan Shelf	39F3			
	Wing Bolt (2)	a39F3§			
18F		b39F3			
a18F	Galley Pan Support	39F4			
b18F	Galley Pan Support, Reverse Delivery Attachment (see Plate 46)	39F5			
c18F	Galley Pan Support, Leading Attachment (see Plate 47)	39F6			
a18F1	Bar (2)	a39F6			
18F2	Bevel Nut (3)	39F7			
a18F3	Bevel Nut Wing Bolt (3)	a39F7			
18F4	Block, for Galley Bar	39F8			
18F5	Corner Block, rear, for Galley Pan	a39F8			
18F6	Corner Block, front, for Galley Pan	39F9			
a18F7	Set Screw (2), $\frac{5}{16}'' \times \frac{3}{4}''$, Reverse Delivery Attachment	39F10			
b18F7	Wing Bolt (2)	b39F14§			
a18F8	Bevel Nut Wing Bolt Washer (3)	a39F15			
Xa18F	Galley Pan Support group; consists of a18F, a18F1(2), 18F2(3), a18F3(3), 18F4, 5 and 6, b18F7(2), a18F8(3)	a39F16			
Xb18F	Galley Pan Support, Reverse Delivery Attachment, group; consists of b18F, a18F1(2), 18F2(3), a18F3(3), 18F4, 5 and 6, a18F7(2), a18F8(3)	a39F18§			
32F		a39F19			
b32F	Operating Lever	39F22			
33F		a39F24			
a33F7	Operating Lever Latch Shaft	39F25			
34F		39F26			
34F	Operating Lever Latch Spring	39F29			
35F					
35F	Operating Lever Latch Spring Post, in Main Galley Stand				
36F					
	Operating Lever Latch Stand				
	Bolt (2), $\frac{5}{16}'' \times \frac{7}{8}''$, hexagon				
	Operating Lever Latch Stand group; consists of a36F, 36F1(2)				
37F					
	Operating Lever Spring Box (Not supplied separately, order X37F)				
	Operating Lever Spring Box, Display Attachment (see Plate 37)				
	Operating Lever Spring Box, Variable Speed Cone Drive Attachment (Not supplied separately, order Xb37F)				
	Plunger (see Plate 37)				
	Plunger Stop Taper Pin (see Plate 37)				
	Spring				
	Spring, Display Attachment				
	Cam, Display Attachment (see Plate 37)				
	Operating Lever Spring Box group; consists of 37F, 37F1, 2 and 3				
	Operating Lever Spring Box, Display Attachment, group; consists of a37FF, 37F1, a37F3				
	Operating Lever Spring Box, Variable Speed Cone Drive Attachment, group; consists of b37F, 37F1, 2 and 3 (see Plate 56)				
	*a37FF consists of a37F, 37F2, a37F5				
	†Can be fitted only at Workshops				
39F					
	Rule, Reverse Delivery Attachment (see Plate 46)				
	Rule (see Plate 19)				
	Rule, Leading Attachment (see Plate 47)				
	Guide Pin (see Plate 19)				
	Guide Pin, Leading Attachment (see Plate 47)				
	Guide Pin Rivet (2)				
	Lifting Rod				
	Lifting Rod, Reverse Delivery Attachment (see Plate 46)				
	Lifting Rod, Leading Attachment (see Plate 47)				
	Lifting Rod Adjusting Nut				
	Lifting Rod Adjusting Nut Lock Nut				
	Lifting Rod Sleeve				
	Lifting Rod Sleeve, Reverse Delivery Attachment (see Plate 46)				
	Lifting Rod Spring				
	Lifting Rod Spring, Leading Attachment (see Plate 47)				
	Lifting Rod Support (Not supplied separately, order e39FF)				
	Lifting Rod Support, Leading Attachment (Not supplied separately, order h39FF)				
	Lifting Rod Support Rivet (4)				
	Lifting Rod Washer, Composition Caster (2), Reverse Delivery and Leading Attachments (3)				
	Lifting Rod Bracket, Reverse Delivery Attachment (see Plate 46)				
	Lifting Rod Bracket Wing Bolt, Reverse Delivery Attachment (see Plate 46)				
	Lifting Rod Bracket Wing Bolt Washer, Reverse Delivery Attachment (see Plate 46)				
	Support, Reverse Delivery Attachment (see Plate 46)				
	Support Rivet (4), Reverse Delivery Attachment				
	Lifting Rod Bearing Bracket Screw (2), $\frac{1}{4}'' \times \frac{11}{16}''$, to Main Galley Stand, Leading Attachment (see Plate 48)				
	Lifting Rod Bearing Bracket, Leading Attachment (see Plate 48)				
	Lifting Rod Bearing Bracket Bush, Leading Attachment (see Plate 48)				
	Lifting Rod Bearing Bracket Bush Nut, Leading Attachment (see Plate 48)				
	Lifting Rod Collar (This part is fitted to new Composition Casters which are equipped with Leading Attachment at Works, replaces Type Channel Plate Bush, 49F9, Dowels, 49F10(2), Screws, 49F11(2))				
	Lifting Rod Distance Piece, Overhung Type Attachment (see Plate 44)				
	Lifting Rod Stop Bracket Pin				
	Lifting Rod Stop Bracket				
	Spring Clip, for Support, Lead and Rules, Leading Attachment (see Plate 47)				
	Lifting Rod Stop Bracket				
	Rule, Reverse Delivery Attachment, group; consists of c39FF, a39F3, 39F4 and 5, a39F6, 39F7, 39F10(3), b39F14, a39F15 and 16				
	Rule, Leading Attachment, group; consists of h39FF, 39F4, 5 and 6, a39F7, 39F10(3), 39F22(2), a39F24, 39F25 and 26, 39F31, 32 and 33				
	Rule group; consists of e39FF, 39F4 to 7 inclusive, 39F10(2), 39F31 and 32, 39F34				
	*c39FF consists of c39F, a39F18, a39F19(4)				
	†e39FF consists of e39F, c39F1, a39F2(2), 39F3, 39F8, 39F9(4)				
	‡h39FF consists of h39F, d39F1, a39F2(2), b39F3, a39F8, 39F9(4)				
	§Can be fitted only at Workshops				
40F					
a40F	Rule Lever (Not supplied separately, order Xa40F)				
c40F	Rule Lever, Reverse Delivery Attachment (Not supplied separately, order Xc40F)				
40F1	Cam Roller				
40F3	Cam Roller Pin				
40F4	Cam Roller Pin Nut				
40F5	Cam Roller Pin Washer				
Xa40F	Rule Lever group; consists of a40F, 40F1, 40F3, 4 and 5				
Xc40F	Rule Lever, Reverse Delivery Attachment, group; consists of c40F, 40F1, 40F3, 4 and 5 (see Plate 46)				
41F					
41F	Rule Lever Stud				
42F					
b42F	Tool Tray, Reverse Delivery Composition, Reverse Delivery Attachment (see Plate 46)				
c42F	Tool Tray (Not supplied separately, order Xc42F)				
d42F	Tool Tray, English Composition, Reverse Delivery Attachment (Not supplied separately, order Xd42F)				
42F2	Clamp Screw, Reverse Delivery Attachment (see Plate 46)				
42F3	Clamp Screw Bevel Nut, Reverse Delivery Attachment (see Plate 46)				
42F4	Catch, for Trip Lever				
a42F5	Catch Pin				
42F6	Catch Pin Spring Washer				
Xb42F	Tool Tray, Reverse Delivery Composition, Reverse Delivery Attachment, group; consists of b42F, 42F2 and 3				
Xc42F	Tool Tray group; consists of c42F, 42F4, a42F5, 42F6				
Xd42F	Tool Tray, English Composition, Reverse Delivery Attachment, group; consists of d42F, 42F4, a42F5, 42F6				
43F					
a43FF*	Tool Tray Support Bar				
43F1	Stud, long				
a43F1	Stud, for Fulcrum Bar, Galley Trip (Sorts) Attachment (see Plate 44)				
b43F1	Stud, long, Reverse Delivery Attachment (see Plate 45)				
43F2	Stud, short				
a43F2	Stud, short, Reverse Delivery Attachment (see Plate 45)				
43F3	Stud Nut, Composition Caster (2), Reverse Delivery Attachment (4)				
a43F3	Stud Nut, Galley Trip (Sorts) Attachment (see Plate 44)				
a43F4	Post, for Tool Tray				
43F5	Post Nut, knurled				
43F6	Stud Washer, Galley Trip (Sorts) Attachment (see Plate 44)				
Xa43F	Tool Tray Support Bar group; consists of a43FF, 43F1 and 2, 43F3(2), 43F5				
	*a43FF consists of a43F, a43F4				