

Unit Adding Attachment, new style
81CU6 **Two-Colour Attachment**; consists of 1A29 to 33 inclusive, d29AA, 43A1 assd., 43A7(2), d16E20, b16E23, 16E24, 16E35, a16E36, 36E155, 36E156(3), 36E157(3), 36E158

73H

AIR BLOWER ATTACHMENT

73H1* **Blower Casing**
73H2 Adjusting Screw, $\frac{1}{4}'' \times \frac{7}{16}''$, in Casing
73H3 Adjusting Screw Lock Screw, $\frac{5}{32}'' \times \frac{1}{4}''$
73H4 Lock Screw (2), $\frac{3}{8}'' \times 1\frac{3}{8}''$, hexagon, to Blower Support Bracket
73H5 Lock Screw Washer (2)
73H6 Oiler, for Rotor Blades
73H7 Pivot Screw, to Blower Support Bracket
X73H* Blower Casing group; consists of 73H1, 2 and 3, 73H4(2), 73H5(2), 73H6 and 7

*Can be fitted only at Workshops

75H

AIR BLOWER ATTACHMENT

75H1* **Blower Casing Cover, front**
75H2* Ball Bearing, for Rotor
75H3 Dowel Pin (2), to Casing
75H4 Grease Cup
75H5 Plate
75H6 Plate Screw (4), $\frac{1}{8}'' \times \frac{1}{4}''$, to Cover
75H7 Screw (4), $\frac{1}{4}'' \times \frac{5}{8}''$, to Casing
X75H* Blower Casing Cover, front, group; consists of 75H1 and 2, 75H3(2), 75H4 and 5, 75H6(4), 75H7(4)

*Can be fitted only at Workshops

76H

AIR BLOWER ATTACHMENT

76H1* **Blower Casing Cover, rear**
76H2* Ball Bearing, for Rotor
76H3 Dowel Pin (2), to Casing
76H4 Grease Cup
76H5 Plate
76H6 Plate Screw (4), $\frac{1}{8}'' \times \frac{1}{4}''$, to Cover
76H7 Screw (2), $\frac{1}{4}'' \times 1\frac{3}{8}''$, to Casing
76H8 Screw (2), $\frac{1}{4}'' \times \frac{5}{8}''$, to Casing
X76H* Blower Casing Cover, rear, group; consists of 76H1 and 2, 76H3(2), 76H4 and 5, 76H6(4), 76H7(2), 76H8(2)

*Can be fitted only at Workshops

77H

AIR BLOWER ATTACHMENT

77H1 **Blower Pulley**

78H

AIR BLOWER ATTACHMENT

78H1 **Blower Rotor**
78H2 Blade (8)
78H3 Screw, for Pulley
X78H Blower Rotor group; consists of 78H1, 78H2(8), 78H3

79H

AIR BLOWER ATTACHMENT

79H1 **Blower Support Bracket**

84CT

AIR BLOWER ATTACHMENT

a84CT1 **Motor Pulley**
a84CT2 Lock Screw

85CU

Air Blower Attachment

Object—To save initial cost and running expenses of Compressor, Motor and Tank (for Customer having only, or wishing to run only, a Type and Rule Caster

85CU1 **Air Blower Attachment**; consists of a1H21, 1H22, 1H23(2), 1H24(2), 1H25, X73H, X75H, X76H, 77H1, X78H, 79H1, b, c or d24CT47, a84CT1 and 2

Note—This Attachment is applicable only to A.C. 2- or 3-phase and D.C. Motor Drives, as the Motor Pulley a84CT1 is not suitable for single phase Motors