

## ATTACHMENT a18KU1

## BOOK COPY HOLDER

This enables a complete book to be held conveniently when copy is being composed from it.

It consists of a frame to support the book, with a wide shelf below, whilst suitable fingers are provided to keep the pages of the book parted at the required place.

To fit the attachment it is only necessary to remove the standard copy holder from the extension b3KA2.

Slide the book copy holder on to the extension by passing the latter through the hole in the bracket b23KA6. Place the holder in the most convenient position, then tighten the thumb screw a23KA7.

## ATTACHMENT 21KU

## TABULAR COPY HOLDER

This is a large holder intended for the use of tabular copy and large-dimensioned copy generally, such as loose-leaf copy.

It is equipped with a slide for marking the place on the copy.

The attachment is provided with a clip which allows it to be held in the standard copy holder rollers.

## ATTACHMENT b22KU1

## PAPER PERFORATING ATTACHMENT

This attachment is for perforating the marginal holes in a blank roll of paper of standard width while the keyboard is being ordinarily operated. It will accommodate a roll up to 7" diameter.

It comprises a frame mounted on top of the paper tower to carry the paper roll, and a perforating mechanism situated at the rear of the paper tower. The latter is operated by a connecting rod connected to the tension arm piston rod.

To fit the attachment to the keyboard: Turn off air. Remove paper guide xa45KC, paper spool guide xb46KC and screws 47KC1, rear punch bar guide a18KC45, rear cover xa19KC, and tension arm piston rod 40KC1.