2F

a2F **Column Pusher Adjusting Cam,** point (Not supplied separately, order Xa2F)
b2F Column Pusher Adjusting Cam, didot (Not supplied separately, order Xb2F)
*a2F1** Disc (see Plate 19)
*b2F1** Disc, Reverse Delivery Attachment (see Plate 46)
2F2 Disc Pin (see Plate 19)
2F3 Disc Taper Pin
Xa2F Column Pusher Adjusting Cam, point, group; consists of a2F, a2F1, 2F2 and 3
Xb2F Column Pusher Adjusting Cam, didot, group; consists of b2F, a2F1, 2F2 and 3
*Can be fitted only at Workshops

3F

a3FF* **Column Pusher Adjusting Cam Stand**
a3F1 Spring
a3F2 Stud
3F3 Stud Nut (2)
Xa3F Column Pusher Adjusting Cam Stand group; consists of a3FF, 3F3(2)
*a3FF consists of a3F, a3F1 and 2

15F

Galley Cam Shaft
15F3 Worm Wheel
a15F4 Worm Wheel Oil Pan

16F

16F **Galley Cam Stand**
16F1 Taper Pin, $\frac{11}{32}'' \times 1\frac{1}{2}''$
16F2 Screw (4), $\frac{3}{8}'' \times \frac{7}{8}''$
X16F Galley Cam Stand group; consists of 16F, 16F1, 16F2(4)

17F

Galley Pan Shelf
a17F6 Wing Bolt (2)

18F

a18F **Galley Pan Support**
b18F Galley Pan Support, Reverse Delivery Attachment (see Plate 46)
c18F Galley Pan Support, Leading Attachment (see Plate 47)
a18F1 Bar (2)
18F2 Bevel Nut (3)
a18F3 Bevel Nut Wing Bolt (3)
18F4 Block, for Galley Bar
18F5 Corner Block, rear, for Galley Pan
18F6 Corner Block, front, for Galley Pan
a18F7 Set Screw (2), $\frac{5}{16}'' \times \frac{3}{4}''$, Reverse Delivery Attachment
b18F7 Wing Bolt (2)
a18F8 Bevel Nut Wing Bolt Washer (3)
Xa18F Galley Pan Support group; consists of a18F, a18F1(2), 18F2(3), a18F3(3), 18F4, 5 and 6, b18F7(2), a18F8(3)
Xb18F Galley Pan Support, Reverse Delivery Attachment, group; consists of b18F, a18F1(2), 18F2(3), a18F3(3), 18F4, 5 and 6, a18F7(2), a18F8(3)

32F

b32F **Operating Lever**

33F

Operating Lever Latch
a33F7 Shaft

34F

34F **Operating Lever Latch Spring**

35F

35F **Operating Lever Latch Spring Post,** in Main Galley Stand

36F

a36F **Operating Lever Latch Stand**
36F1 Bolt (2), $\frac{5}{16}'' \times \frac{7}{8}''$, hexagon
Xa36F Operating Lever Latch Stand group; consists of a36F, 36F1(2)

37F

37F **Operating Lever Spring Box** (Not supplied separately, order X37F)
*a37FF** Operating Lever Spring Box, Display Attachment (see Plate 37)
b37F Operating Lever Spring Box, Variable Speed Cone Drive Attachment (Not supplied separately, order Xb37F)
37F1 Plunger (see Plate 37)
37F2 Plunger Stop Taper Pin (see Plate 37)
37F3 Spring
a37F3 Spring, Display Attachment
a37F5† Cam, Display Attachment (see Plate 37)
X37F Operating Lever Spring Box group; consists of 37F, 37F1, 2 and 3
Xa37F Operating Lever Spring Box, Display Attachment, group; consists of a37FF, 37F1, a37F3
Xb37F Operating Lever Spring Box, Variable Speed Cone Drive Attachment, group; consists of b37F, 37F1, 2 and 3 (see Plate 56)
*a37FF consists of a37F, 37F2, a37F5
†Can be fitted only at Workshops

39F

*c39FF** **Rule,** Reverse Delivery Attachment (see Plate 46)
e39FF† Rule (see Plate 19)
h39FF‡ Rule, Leading Attachment (see Plate 47)
c39F1§ Guide Pin (see Plate 19)
d39F1§ Guide Pin, Leading Attachment (see Plate 47)
a39F2 Guide Pin Rivet (2)
39F3 Lifting Rod
a39F3§ Lifting Rod, Reverse Delivery Attachment (see Plate 46)
b39F3 Lifting Rod, Leading Attachment (see Plate 47)
39F4 Lifting Rod Adjusting Nut
39F5 Lifting Rod Adjusting Nut Lock Nut
39F6 Lifting Rod Sleeve
a39F6 Lifting Rod Sleeve, Reverse Delivery Attachment (see Plate 46)
39F7 Lifting Rod Spring
a39F7 Lifting Rod Spring, Leading Attachment (see Plate 47)
39F8 Lifting Rod Support (Not supplied separately, order e39FF)
a39F8 Lifting Rod Support, Leading Attachment (Not supplied separately, order h39FF)
39F9 Lifting Rod Support Rivet (4)
39F10 Lifting Rod Washer, Composition Caster (2), Reverse Delivery and Leading Attachments (3)
b39F14§ Lifting Rod Bracket, Reverse Delivery Attachment (see Plate 46)
a39F15 Lifting Rod Bracket Wing Bolt, Reverse Delivery Attachment (see Plate 46)
a39F16 Lifting Rod Bracket Wing Bolt Washer, Reverse Delivery Attachment (see Plate 46)
a39F18§ Support, Reverse Delivery Attachment (see Plate 46)
a39F19 Support Rivet (4), Reverse Delivery Attachment
39F22 Lifting Rod Bearing Bracket Screw (2), $\frac{1}{4}'' \times \frac{15}{16}''$, to Main Galley Stand, Leading Attachment (see Plate 48)
a39F24 Lifting Rod Bearing Bracket, Leading Attachment (see Plate 48)
39F25 Lifting Rod Bearing Bracket Bush, Leading Attachment (see Plate 48)
39F26 Lifting Rod Bearing Bracket Bush Nut, Leading Attachment (see Plate 48)
39F29 Lifting Rod Collar (This part is fitted to new Composition Casters which are equipped with Leading Attachment at Works, replaces Type Channel Plate Bush, 49F9, Dowels, 49F10(2), Screws, 49F11(2)
39F30 Lifting Rod Distance Piece, Overhung Type Attachment (see Plate 44)
39F31 Lifting Rod Stop Bracket Pin
39F32 Lifting Rod Stop Plate
39F33 Spring Clip, for Support, Lead and Rules, Leading Attachment (see Plate 47)
39F34 Lifting Rod Stop Bracket
Xk39F Rule, Reverse Delivery Attachment, group; consists of c39FF, a39F3, 39F4 and 5, a39F6, 39F7, 39F10(3), b39F14, a39F15 and 16
Xm39F Rule, Leading Attachment, group; consists of h39FF, 39F4, 5 and 6, a39F7, 39F10(3), 39F22(2), a39F24, 39F25 and 26, 39F31, 32 and 33
Xp39F Rule group; consists of e39FF, 39F4 to 7 inclusive, 39F10(2), 39F31 and 32, 39F34
*c39FF consists of c39F, a39F18, a39F19(4)
†e39FF consists of e39F, c39F1, a39F2(2), 39F3, 39F8, 39F9(4)
‡h39FF consists of h39F, d39F1, a39F2(2), b39F3, a39F8, 39F9(4)
§Can be fitted only at Workshops

40F

a40F **Rule Lever** (Not supplied separately, order Xa40F)
c40F Rule Lever, Reverse Delivery Attachment (Not supplied separately, order Xc40F)
40F1 Cam Roller
40F3 Cam Roller Pin
40F4 Cam Roller Pin Nut
40F5 Cam Roller Pin Washer
Xa40F Rule Lever group; consists of a40F, 40F1, 40F3, 4 and 5
Xc40F Rule Lever, Reverse Delivery Attachment, group; consists of c40F, 40F1, 40F3, 4 and 5 (see Plate 46)

41F

41F **Rule Lever Stud**

42F

b42F **Tool Tray,** Reverse Delivery Composition, Reverse Delivery Attachment (see Plate 46)
c42F Tool Tray (Not supplied separately, order Xc42F)
d42F Tool Tray, English Composition, Reverse Delivery Attachment (Not supplied separately, order Xd42F)
42F2 Clamp Screw, Reverse Delivery Attachment (see Plate 46)
42F3 Clamp Screw Bevel Nut, Reverse Delivery Attachment (see Plate 46)
42F4 Catch, for Trip Lever
a42F5 Catch Pin
42F6 Catch Pin Spring Washer
Xb42F Tool Tray, Reverse Delivery Composition, Reverse Delivery Attachment, group; consists of b42F, 42F2 and 3
Xc42F Tool Tray group; consists of c42F, 42F4, a42F5, 42F6
Xd42F Tool Tray, English Composition, Reverse Delivery Attachment, group; consists of d42F, 42F4, a42F5, 42F6

43F

a43FF* **Tool Tray Support Bar**
43F1 Stud, long
a43F1 Stud, for Fulcrum Bar, Galley Trip (Sorts) Attachment (see Plate 44)
b43F1 Stud, long, Reverse Delivery Attachment (see Plate 45)
43F2 Stud, short
a43F2 Stud, short, Reverse Delivery Attachment (see Plate 45)
43F3 Stud Nut, Composition Caster (2), Reverse Delivery Attachment (4)
a43F3 Stud Nut, Galley Trip (Sorts) Attachment (see Plate 44)
a43F4 Post, for Tool Tray
43F5 Post Nut, knurled
43F6 Stud Washer, Galley Trip (Sorts) Attachment (see Plate 44)
Xa43F Tool Tray Support Bar group; consists of a43FF, 43F1 and 2, 43F3(2), 43F5
*a43FF consists of a43F, a43F4