

designed to 12 units may be placed in the 10-unit row of matrix-case, and composed and cast to 12 units.)

The device is mainly used in German composition for spacing words in Fraktur type to serve a similar purpose to the use of italics in roman type.

Particulars regarding fitting and applying this attachment may be had on application to The Monotype Corporation Limited, 55-56 Lincolns Inn Fields, London, W.C.2.

ATTACHMENT b10KU

3-UNIT MINIMUM JUSTIFYING SPACE ATTACHMENT

This is provided to supply justifying spaces one unit smaller than the minimum justifying spaces provided by the standard equipment on the keyboard.

The attachment consists of a special unit rack stop, a special unit rack stop guide fitted with a unit rack stop to give three units registration, and a controlling handle. A special keybank button lever in each keybank will be needed if not already fitted, and corresponding special keybars placed in the keybar frames (if not already there).

When narrow spaced copy is to be set, the lugs on the keybank space button levers must be turned to engage the special keybars, and the lugs used for normally spaced copy must be moved out of engagement with their corresponding keybars; also the control lever on the unit rack stop guide must be positioned to the left. This causes all variable spaces to be registered three units.

To fit this attachment remove the unit rack stop guide xc33KB and bracket xa76KB by withdrawing the screws (2) 76KB2. Remove the screws (2) a76KB4 and shoe a76KB3. Take the adjusting screw a33KB4 and nut a33KB5 (removed from the keyboard) and fit them to the attachment guide g33KB1k, first filing clearance for operating handle a33KB6 on the lower edge of bracket b76KB1, as shown on the drawing supplied with the attachment. Replace the shoe a76KB3 and screws (2) a76KB4 and fit the attachment with the modified guide to the keyboard.

It will be necessary to check the adjustment of a33KB4, controlling the meshing of the unit wheel pawl with the teeth of unit wheel.